


# QUICK START GUIDE



**KEPCO** An ISO 9001 Company.

**HSP-A**  
1000W/1500W CE

## SINGLE OUTPUT PROGAMMABLE POWER SUPPLIES

### I — INTRODUCTION

**SCOPE OF MANUAL** This Quick Start Guide covers the installation and operation of the Kepco HSP-A Series of voltage and current stabilized d-c power supplies. Full specifications are listed in the applicable Operator's Manual that can be downloaded from the Kepco web site at

[www.kepcopower.com/support/opmanls.htm/#hsp](http://www.kepcopower.com/support/opmanls.htm/#hsp)

HSP-A are intended for installation in the RA 90 Series of Rack Adapters. Users must refer to the RA90 Series Quick Start Guide and Operator manual for connection and configuration details. Both can be downloaded from the Kepco web site at


[www.kepcopower.com/support/opmanls.htm/#ra90](http://www.kepcopower.com/support/opmanls.htm/#ra90)

**FACTORY DEFAULTS** This guide covers only units as shipped from the factory with the three DIP switches set to default configuration (see Figure 1). For other configurations, refer to HSP-A Operator Manual.

**DESCRIPTION** The HSP-A power supply (Figure 1-1) is basically a voltage and current stabilized d-c source with a relatively sharp crossover between voltage and current mode operation.

HSP-A power supplies are nominally rated at either 1000 or 1500 Watts of output power, and include active power factor correction (PFC). HSP-A 1000W power supplies are designed to operate over the universal a-c power mains voltage range of 90-277V (47-63Hz), with operation from 125-420V d-c also available. HSP-A 1500W products provide full power over the a-c mains range of range of 180-277V a-c, and 1000W output power from 90-132V a-c; contact Kepco for information on operation over other source voltage ranges. Cooling is provided via an internal d-c fan.

HSP-A permits adjustment of both output voltage ( $V_O$ ) and current limit ( $I_{MAX}$ ), either by internal (front panel pot) or external (resistance or voltage) methods, selected via DIP switches accessed through the top of the unit. Protection against overvoltage, overcurrent and overtemperature failures is provided.



**FIGURE 1. DIP SWITCH FACTORY DEFAULTS**

The HSP-A power supply is specifically designed for use with Kepco RA 90 Series or similar plug-in rack adapters as a hot replaceable module in a redundant power system. Bench top operation not supported. Forced current sharing and built-in output blocking diodes enhance power system reliability. Mechanical keying eliminates the risk of incorrect module insertion. Tool-operated latches on the front panel guard against casual removal of an operating module.

**OPTIONS** M models include a digital meter which displays either voltage or current as determined by a front panel switch. Another switch allows display of either actual HSP-A Output or the setpoint. MT models include a separate switch that allows the meter to display internal unit temperature, plus an analog signal proportional to internal generator; T models include the analog signal only (no meter). L models include built-in free-wheeling (flyback) diodes used to clamp negative voltage spikes when used with inductive loads. S models include a variable-speed fan whose speed is controlled by internal unit temperature.

B models are intended for battery charging applications, and include a Float/Equalize switch to preset two different voltage values using two separate front panel adjustment pots.

TABLE 1. HSP-A SERIES MODELS

MODELS <sup>(1)</sup>	3.3V	5V	12V	15V	24V	28V	48V	125V
1000W	HSP 3.3-230AR	HSP 5-200AR	HSP 12-84AR	HSP 15-66AR	HSP 24-42AR	HSP 28-36AR	HSP 48-21AR	HSP 125-8AR <sup>(2)</sup>
1500W	N/A	N/A	N/A	N/A	HSP 24-60R	HSP 28-53R	HSP 48-30R	HSP 125-12R <sup>(2)</sup>

(1) Options include suffix M or B: M for meter; B for battery charger

(2) CE Marked, Not UL listed.

## II — INSTALLATION

KEYING. The units are keyed by voltage at the factory.

Refer to the Operator Manual for details.

MOUNTING THE POWER SUPPLY To insert in a Kepco RA 90 Series Rack Adapter, release the two cap head screw retaining latches (see Figure 4) by loosening the cap-head screw approximately 1/2 turn CCW (use 5/32" hex key) and slide to open (up) position. Insert power supply in the slot, then retighten the cap-head screws CW until snug. **DO NOT OVERTIGHTEN!** To release, follow the same procedure, except lift the latch to the top of the slot. Be sure to move the latch completely up or down to ensure full engagement/disengagement of the latching mechanism. When HSP-A is not installed in rack adapter, secure latch in open (up) position to prevent damage.

To use as a fixed, rack-mounted unit, see Operator manual for details and accessories.

For all installations, provide adequate clearance around air inlet and exhaust locations.

CONNECTIONS: Connections to the rack adapter are made via the 47-pin connector at the rear of the HSP-A (see Figure 2). All other connections are made at the rear panel of the RA 90 Series rack adapter. Refer to the RA 90 Series Quick Start Guide and/or Operator Manual for load, sense, current share and alarm connections. **NOTE: Either local or remote sensing must be configured, otherwise the power supply will not work.**

PRELIMINARY ELECTRICAL CHECK A simple operational check after unpacking and before equipment installation is advisable to ascertain whether the power supply has suffered damage resulting from shipping.

1. **Power supply will not operate unless remote sense lines are properly connected to output terminals!** Connect sense terminals to output bus bars using Input Power/Communication Cable (Kepco P/N 118-1432) or other means as shown in Figure 3.




FIGURE 2. HSP-A SERIES REAR PANEL CONNECTIONS

2. Connect power supply to source power. Connection can be made using either a North American linecord set (Kepco P/N 118-0776) or using a custom linecord terminated at one end with an IEC 320/C19 plug (Kepco P/N 142-0381).
3. Connect a static load, R, across output terminals. Load value is determined by HSP nominal output voltage and must be capable of handling 2% of power supply output rating (20 watts minimum). R is calculated as **approximately** equal to output voltage<sup>2</sup>/20 ( $R = E^2/P$ ). For example, for the HSP-A 48-21,  $R = 48^2/20 = 115.2$ ; use load of 120 ohms, 20W.

**TABLE 2. HSP-A/RACK ADAPTER INTERFACE CONNECTOR PIN ASSIGNMENTS**

PIN NO.	NAME	DESCRIPTION OF FUNCTION
1 - 10	(+)	Positive output
11 - 20	(-)	Negative output
21	-S	Negative error sense input
22	+S	Positive error sense input
23	V ORing	Output voltage prior to ORing diode.
24	VSET	Output voltage setpoint monitor (0 - 10V) <sup>(2)</sup>
25	VRP1 (VPROG)	Analog programming input - voltage (0 - 10V) <sup>(2)</sup>
26	VRP2	Resistive programming input - voltage (0 - 50k)
27	IPROG	Analog programming input - current (0 - 10V) <sup>(2)</sup>
28	ISET	Current limit setpoint monitor (0 - 10V) <sup>(2)</sup>
29	ISHARE	Load share signal bus (0 - 5.5V) <sup>(2)</sup>
30	IMON	Analog output current monitor (0 - 5.5V) <sup>(2)</sup>
31	PSS-2	Output status - normally closed contact
32	PSS-1	Output status - normally open contact
33	ACS-2	Source power status - normally closed contact
34	OTS-1	Overtemp status - normally closed contact
35	RC1	Remote inhibit - normally high input <sup>(1)</sup>
36	OTS-2	Overtemp status - normally open contact
37	PSS-C & OTS-C	Common contact for output status and Overtemp status
38	FANRTN	Return for fan (auxiliary) supply
39	RC2	Remote inhibit - normally low input <sup>(1)</sup>
40	5VAUX	Auxiliary (fan) supply output
41	ACS-1	Source power status - normally open contact
42	ACS-C & FFS-C	Common contact for source power status and fan status
43	FFS-2	Fan status - normally open contact
44	FFS-1	Fan status - normally closed contact
45	GND	A-c input voltage - Ground
46	N	A-c input voltage - Neutral
47	L	A-c input voltage - Line

(1) These signals are referenced to fanrtn (pin 38).

(2) These signals are referenced to -S (pin 21).


4. **CAUTION: DO NOT repeatedly toggle circuit breaker as this may damage unit.** Set Power ON/OFF circuit breaker on front panel to ON. If actuator does not lock when released, wait a few seconds before trying again. The circuit breaker is “trip-free” design; if overload exists, contacts cannot be held closed by actuator. Verify that POWER indicator is lit, and that all other front panel indicators are not lit.

5. Using a DVM, measure voltage across output bus bars; this voltage is factory set to value shown in Table 1. If necessary, adjust output voltage using  $V_O$  trim pot accessed through front panel.
6. Using DVM, measure voltage across test points  $V_O$  and COM; it should read 1/10 of output voltage measured in step 5 above,  $\pm 1\%$ .
7. Using DVM, measure voltage across test points  $I_{MAX}$  and COM. This voltage is factory adjusted to 10.0V, and corresponds to 100% of maximum current. Refer to Operator manual for adjustment.
8. Verify that front panel indicators still appear as in step 4 above.
9. Disconnect sense lines with power supply still operating (open +S sense line connected to pin 22). Verify that HSP-A output turns off, and DC FAIL indicator is now lit along with POWER indicator. (NOTE: At no load the output voltage will drop slowly.) Turn circuit breaker off and wait until DC FAIL indicator blinks. Reconnect sense lines, then turn circuit breaker back on. Verify that output voltage returns to value measured in step 5 above, and that indicator LEDs appear as in step 4 above.
10. Turn off front panel circuit breaker and remove source power connection.

NOTES:

CONNECTIONS FOR TEMPORARY BENCHTOP OPERATION SHOWN.

FOR RACK ADAPTER, CONNECT -S AND +S TO (-) AND (+) USING RACK ADAPTER DIP SWITCHES OR CONNECT -S AND +S FROM TERMINAL BLOCK TO RACK ADAPTER (-) AND (+) OUTPUT STUDS, RESPECTIVELY, AT EACH POPULATED POSITION.



3044555

**FIGURE 3. LOAD CONNECTIONS, PRELIMINARY ELECTRICAL CHECKOUT**

### III — OPERATION

**CAUTION: DO NOT repeatedly toggle the circuit breaker/switch as this may damage the unit.** Set Power ON/OFF circuit breaker to ON. When output voltage is available, the green POWER LED is on (see Figure 4).

**OUTPUT VOLTAGE PROGRAMMING** Monitor output voltage setpoint across  $V_O$  and COM jacks while adjusting  $V_O$  pot on front panel. Voltage across  $V_O$  and COM represents 1/10 of the programmed output voltage. As an example,  $V_O$  of 4.63V corresponds to a programmed output voltage of 46.3V ±1%. This relationship is constant, regardless of the programming range selected.

Default programming resolution is set to high range: output can be adjusted to 110% of nominal  $V_O$  for 3.3V through 28V models, 125% of nominal  $V_O$  for 48V models. For low range (which offers increased resolution, while limiting output to  $V_O$ ), or for external voltage programming using either resistance or voltage refer to Operator manual.

For metered (M option) units, if the V/A switch is set to V, actual output voltage is displayed on the meter in Volts. While the ACTUAL/SETPOINTS switch is held in, the programmed output voltage setpoint is displayed in Volts.

**CURRENT LIMIT PROGRAMMING** Monitor current limit setpoint across  $I_{MAX}$  and COM jacks while adjusting  $I_{MAX}$  pot on front panel. Voltage across  $I_{MAX}$  and COM represents the percentage of available power supply current as a percentage of rated current, with 10V corresponding to 100%. Available current is defined as the maximum current limit available based on the programming range. This voltage is always based on a 0-10V scale, regardless of the range selected. For example,  $I_{MAX} = 6.2V$  corresponds to 62% of the maximum programmable current. For the low programming range, this corresponds to 62% of the rated module current, but for the high programming range the number is 62% of 110%, or 68.2% of rated module current. Current setpoint monitor accuracy is ±5%.

Minimum programmable current limit is 50-60% of nominal. Default programming resolution is set to high range: current limit can be adjusted to 110% of nominal  $I_O$ . For low range (which offers increased resolution, while limiting output to  $I_O$ ), or for external programming using voltage source refer to Operator manual.

For metered (M option) units, if the V/A switch is set to A, actual output current is displayed on the meter in Amperes. While the ACTUAL/SETPOINTS switch is held in, the programmed current limit is displayed in Amperes.


**OVERVOLTAGE PROTECTION** The overvoltage protection (OVP) circuitry latches the output regulator off if output voltage rises above a predetermined level. To reset, remove source power for a minimum of 30 seconds (refer to Operator manual to enable remote reset). The trip level is preset at the factory for 130% of the nominal output voltage. The trip point can be adjusted from 100% to 140% of the nominal output (except Model HSP 48-21A, which can be adjusted from 100% to 160% of the nominal output). To alter the preset OVP trip point, refer to the Operator manual.

**CURRENT LIMIT CHARACTERISTIC** The factory default setting is Continuous Limiting: When the output current of the power supply reaches the programmed current limit, the output regulator switches to current mode operation and maintains the output current by modulating output voltage. Current mode is maintained indefinitely, and recovery to voltage regulation mode is automatic upon reduction of output current below the current limit point.

Current Limit can also be set to Undervoltage Lockout: if current mode is maintained for more than 15 seconds, the output is turned off, and source power must be recycled to restart the unit. Refer to HSP-A Operator manual for details.

**OTHER FEATURES** The following features of the HSP-A power supplies are covered in detail in the HSP-A Operator manual:

- Parallel Operation, including load sharing requirements.
- Remote Inhibit, Remote Reset
- Remote Voltage and Current Limit adjustment
- Protection Circuits
- Status Flags and Indicators
- Load Monitor (Current)
- Current “Walk-In” for battery charging applications
- Load monitor
- Auxiliary supply
- Keying
- I/O Connector pin functions
- Options



3044588

**FIGURE 4. COMPONENT LOCATIONS**